

Thermal-Chem 2120 Roberts Drive Broadview, IL 60155 Phone: (847) 288-9090 Fax:(847)288-9091

Fax:(847)288-9091 Toll Free: (800)635-3773

## Standard Tools & Equipment Checklist for Floor Coating Installation

## Floor Prep Tools

- 7"and 4" Grinders and Cup Wheels
- Vacuums and Hoses
- Crack Chaser and Wheels

## **Mixing Tools**

- Variable Speed Drill with 1/2" or 3/8" Chuck
- Mixing Blades
- Timer for Measuring Mix Times
- 5 Gallon Pails
- Screwdriver/ Utility Knives for Opening Plastic Buckets and Sand Bags
- Plastic Measuring Containers (1 quart, 2 1/2 quart, 5 quart)
- Heavy Duty Plastic Tarp or Cardboard for Mixing Station

## **Installation Tools and Supplies**

- 18" Roller Cages
- 9" Roller Cages
- 9", 18", or 24" Squeegees
- Handles for Squeegees and Rollers
- Various Trowels
- Extension Cords
- Blower
- Gauge Rake
- Surface-reading Infrared Thermometer
- Spiked Roller
- Spiked Shoes
- 18" Roller Covers (1/4" or 3/8" Nap)
- 9" Roller Covers (1/4" or 3/8" Nap)



Thermal-Chem 2120 Roberts Drive Broadview, IL 60155 Phone: (847) 288-9090 Fax:(847)288-9091

Toll Free: (800)635-3773

- 2 1/2" Chip Brushes
- Wood Paint Sticks
- Duct Tape
- Blue Tape
- Caution Tape
- Rubber Gloves
- Rags
- Garbage Bags
- Xylene, IPA, or Denatured Alcohol
- Thickening Agent (Cab-O-Sil, Thick-Sil, etc)
- Putty Knives
- Dust Masks
- Ear Protection
- Safety Glasses
- Knee Pads